

OTS PB and OTS AF Range

Fully automatic insulating oil dielectric breakdown testing



- Fully compliant with international and national standards
- New fully compliant withstand tests
- Full Range to suit all user needs
- Easy adjust – locking electrode gap
- Fast precision breakdown detection
- Ultra-fast HV switch off time
- Suitable for mineral, ester and silicon oils

DESCRIPTION

Megger's range of automatic oil test sets performs accurate breakdown and withstand voltage tests on mineral, ester and silicon insulating liquids. Common across the range precision, shatter proof test vessels are easy to clean and provide repeatable results, whether they are used in the field or laboratory featuring lock in precision electrode gap setting adjustment wheels. The transparent, shielded lid and large test chamber allows easy access to the test vessel, enabling users to see what is happening within the test chamber.

All of the current test standards world wide are preloaded in the instrument for convenient automatic operation, however should a new test standard or an existing standard be amended there are 3 custom tests that can be configured to the new requirements. This enables testing to continue to cover the short period while Megger updates the test procedure files. New updated files are then downloaded by the user and installed into the test instrument via a USB memory stick / flash drive.

Test results are identified either by a serial number or asset ID and are time and date stamped. The Megger asset and data management software, PowerDB Lite, is bundled at no extra cost providing an excellent tool for downloading and printing results.

An optional internal printer provides a hard copy of results. Ink based printout ensures durability at all temperatures. USB flash drive for easy transfer of test results, external USB printer and on the AF model a barcode scanner.

User safety is paramount and Megger have designed independent and dual redundant high voltage cut-off circuitry to ensure safety. During a test the operator can terminate by pressing any button on the keyboard which will remove high voltage immediately and abort the test. The transparent lid provides ample visibility within the chamber yet is protected and electrically shielded by a screen with multiple links to instrument ground.

OTS PB models

These 60 kV and 80 kV oil test sets are small and the lightest on the market with weight ranging from 16 kg to 23.5 kg depending on model configuration. They come complete with optional carry bag and transport case. The carry bag has pouches for electrode accessory pack, leads, quick user guide, paper roll etc. these units can be supplied mains powered only, or mains powered and battery operated for additional flexibility in portable applications. The optional batteries are NiMH, or if selecting an 80 kV model a lead acid battery can be specified. In addition, an internal 12 V DC charger and vehicle adaptor cable is standard when any battery option is fitted.

OTS AF models

These 60 kV, 80 kV and 100 kV models have much a larger test chamber for even easier access and cleaning, particularly useful in a lab environment. They are fitted with a 12 key alpha-numeric keypad to facilitate entry of test ID, file names, notes etc. Alpha characters are entered by repetitive pressing on a key. The AF models also have the ability to use a USB barcode reader to scan oil sample barcode labels, ideal for better integration with a LIM system.

APPLICATION

Monitoring and maintenance of oil quality is essential in ensuring the reliable operation of oil filled electrical equipment. Codes of practice have been established in many countries that include several different types of test on insulating oils.

One of the fundamental tests of oil quality is the breakdown voltage test, which is a measure of the oil's ability to withstand electric stress. A low breakdown voltage can indicate the presence of contaminants such as water or conducting particles.

In addition to the breakdown test, the withstand test is a measure of the oils ability to withstand a constant electrical stress. Failure to achieve this also indicates contaminants.

Care should be taken to ensure the process of sampling oil and subsequent testing does not in any way contaminate it with foreign objects. Cleaning vessels between oil tests should be a rinse with the next sample, never clean with fibrous materials. To ensure an accurate reading set gap carefully and lock adjusting wheels.

FEATURES AND BENEFITS

COMMON ACROSS PB AND AF

- Lock in precision oil vessel - lockable gap setting
- Flat electrode gap gauges that will not damage electrodes
- Oil temperature is measured continuously so it can be determined whether the oil test sample is within the range allowed by the test standards before the test is commenced
- QVGA colour display with backlight (easy to read in sunlight or dark conditions)
- Large, easy clean test chamber with oil drain
- High visibility test chamber
- Safe operation with dual redundant micro switches
- Intuitive user interface
- Fully automatic operation with preloaded international test standards
- User configurable test sequences to cover transition period of new / updated test standards (standards maintained via USB updates from Megger)
- All instruments supplied with one 400 ml test vessel in the box as standard, unless the super user kit is specified (see below)
- Built onto rigid box section chassis to prevent flexing on impact that otherwise would damage transformer
- Unique built in chamber drain pipe for easy removal of oil accidentally spilt in test chamber, this can easily be connected to a lab waste system
- Test standards favorites list speeds up selection by only displaying the standards regularly used by the user

OTS PB ADDITIONAL FEATURES AND BENEFITS

- Small and lightweight, lightest on the market starting at 16 kg
- Battery options for portable use

OTS AF ADDITIONAL FEATURES AND BENEFITS

- Barcode scanning capability for oil sample ID
- Extra large test chamber for ease of use in high productivity application

- 12 key alpha-numeric keypad to facilitate entry of test ID, file names, notes etc.

COMMON PB AND AF OPTIONAL ITEMS

- Superuser Kit. This cost effective solution supplies everything you need to carry out effective oil testing.
Includes:
A 150 ml test vessel for low volume testing.
A standard 400 ml test vessel.
A stirrer lid with choice of three impellers.

Additional impellers focused on ASTM and IEC standards and even a useful guide booklet to provide essential advice on how to get the best from you new OTS , ALL FREE.
All of this is supplied in a FREE durable Megger case to easily and safely transport your test essentials.



- Internal printer
- Voltage check unit (VCM100D/CM80D)
- Motorised lid impeller
- Megger supplies as standard with the stirrer lid assembly three impellers. Firstly there's the large red impeller which is useful for very dirty oil. This has larger blades to help ensure the effective circulation of any particulates between the electrodes during the test so that the full potential of their effect on breakdown voltage may be assessed. The other two impellers are alternative impellers. The Impeller on the left is optimised for IEC 60156, whilst the one on the right is ideal for ASTM D1816.
- 150 ml test vessel

OTS60PB OPTIONAL ITEMS






- Factory fitted NiMH battery with 12 V charger and vehicle lead
- Carry bag
- Transport case

OTS80PB OPTIONAL ITEMS

- Factory fitted lead-acid or NiMH battery with 12 V charger and vehicle lead
- Carry bag
- Transport case

OTS60AF, OTS80AF and OTS100AF OPTIONAL ITEMS

- Barcode scanner (USB)

						
		OTS60PB	OTS80PB	OTS60AF	OTS80AF	OTS100AF
* Optional item						
** IEC 60156 recommends a separate test vessel is used for each type of fluid to be tested						
*** Important future proof feature						
Configured to order options						
Printer (built in) or not			■		■	
Internal battery fitted or not			■			
Mains / Line supply lead (plug)			■		■	
Electrode set supplied (IEC ASTM or Universal)			■		■	
Soft Padded carry case			■			
OTS Range Differentiating Features						
Max test voltage	60 kV	■		■		
	80 kV		■		■	
	100 kV					■
Power supply	Lead acid battery option		■			
	NiHM battery option		■			
	Vehicle 12 V skt lead option		■			
	Mains only operation		■		■	
Data management	Internal test result memory		■		■	
	Download results to USB stick		■		■	
	USB stored data download		■		■	
	USB upload of assets to be tested		■		■	
	Barcode scanning capability				■	
	Keypad for easy asset ID and memo entry				■	
Ruggedness	Tough display and chamber lid		■		■	
	Low cost shatter proof test vessel		■		■	
	Large corner protecting rubber feet		■		■	
	Rugged non-flex construction		■		■	
Transport	Transport case		■*			
	Protective carry case		■*			
	Light weight (<23 kg) one man carry		■			
Operating costs	Low cost test vessel (Vessel of each oil **)		■		■	
	Annual full calibration		■		■	
Test standards	Fast favourite list selection		■		■	
	Fully automatic test sequence		■		■	
	Test standards update via USB device ***		■		■	
	Custom tests		■		■	
Cleanliness	Easy pour / clean vessel design		■		■	
	Large test chamber (easy access)				■	
	Test chamber spilt oil drain		■		■	
Accuracy	Continuous oil temperature measurement		■		■	
	Lockable thumb wheel adjustable electrode gap		■		■	
	Voltage output verification unit available		■		■	

SPECIFICATIONS

Test voltage

OTS60PB	0 to 60 kV rms maximum (30 kV - 0 - 30 kV)
OTS80PB	0 to 80 kV rms maximum (40 kV - 0 - 40 kV)
OTS60AF	0 to 60 kV rms maximum (30 kV - 0 - 30 kV)
OTS80AF	0 to 80 kV rms maximum (40 kV - 0 - 40 kV)
OTS100AF	0 to 100 kV rms maximum (50 kV - 0 - 50 kV)

Voltage rise time

0.5kV/s, 2.0kV/s or 3kV/s depending on selected test standard

Voltage rise time accuracy

better than 5%

Voltage resolution and accuracy

0.1 kV $\pm 1\%$ ± 2 digits

Programmed test sequences

ASTM D 1816-04	BS EN 60156-96	SABS EN60156
ASTM D 877A-02	CEI EN 60156-95	VDE0370 part 5
ASTM D 877B-02	IRAM 2341	AS1767.2.1
IEC 60156-95	UNE EN 60156	PA SEV EN60156
Withstand A	BS 5730a AD 30 kV	BS 5730a BCEF 22 kV
Withstand B	BS 5730a AD 40 kV	BS 5730a BCEF 30 kV
BS148/EN60156	NF EN 60156	JIS C 2101-99 (M)
IS 6792	GOST 6581-75	JIS C 2101-99 (S)

plus 3 custom test sequences

Vessels

400 ml (standard)
150 ml (superuser pack / option)

Carefully designed test vessels manufactured from the most chemical resistant clear polymer on the market provides tried and tested reliable test results. Featuring precision electrode alignment and adjustment wheels that lock electrodes in position, the option of a 150ml vessel for low volume oil samples is also available

Temperature measuring range

10 °C to 65 °C
(ASTM D877 requires oils to be within 20 °C and 30 °C)
(IEC 60156 required oil to be within 15 °C and 25 °C)

Temperature sensor resolution

1 °C

Power supply

Line voltage 85 to 265 VAC
Line frequency 50/60 Hz

Battery type

Lead acid 2 x 12 V 4 Ah, (OTS80PB ONLY)
Or NiMH 24 V 2 Ah (OTS60PB or OTS80PB ONLY)

Interface

USB 2.0 compatible
2 x USB type-A (Flash drive, printer, other)
1 x USB type-B (Factory use only, PC or Printer)

Internal printer

(Option)
Matrix impact printer
Paper 57.5 mm wide

External printer Any printer with USB interface and PCL3 driver

Protection Dual safety micro switches on chamber cover

Display 320 x 240 QVGA colour display with backlight

Operating temperature range and humidity

0 °C to +50 °C
80% RH at 40 °C

Storage temperature range and humidity

-30 °C to +65 °C
95% RH at 40 °C

Maximum altitude

2000 m

Safety

Designed in accordance with IEC61010

EMC

Light industrial IEC 61326-1 Class B,
CISPR 22, CISPR 16-1 and CISPR 16-2

Dimensions

OTS60PB	520 mm x 340 mm x 250 mm
OTS80PB	520 mm x 380 mm x 250 mm
OTS60AF	580 mm x 420 mm x 290 mm
OTS80AF	580 mm x 420 mm x 290 mm
OTS100AF	580 mm x 420 mm x 290 mm

Weight

OTS60PB	16 kg (printer, no battery), 16.8 kg (printer, NiMH battery)
OTS80PB	20 kg (printer, no battery), 20.8 kg (printer, NiMH battery), 23.2 kg (printer, lead acid batteries)
OTS60AF	30 kg with printer option fitted
OTS80AF	30 kg with printer option fitted
OTS100AF	30 kg with printer option fitted

Test vessels

1.1 kg (400 ml and 150 ml)

Language

English, French, German, Spanish,
Czech, Dutch, Finnish, Italian, Norwegian,
Polish, Portuguese, Russian and Swedish

Programmed test sequence overview

Standards complied with and programmed	Oil types tested		Electrode gap options (mm)			Electrode shape options			Oil stirring options		Voltage rise rate options			Breakdown test sequence		
	Mineral Ester HMWH	Silicon	1.0	2.0	2.5	2.54			0.5 kV/s	2 kV/s	3 kV/s	Number of tests	Initial stand time	Time between tests		
IEC 60156-95	■	■	■				■	■	■			6	5 mins	2 mins		
BS EN 60156-96	■	■	■				■	■	■			6	5 mins	2 mins		
CEI EN 60156-95	■	■	■				■	■	■			6	5 mins	2 mins		
IRAM 2341	■	■	■				■	■	■			6	5 mins	2 mins		
UNI EN 60156	■	■	■				■	■	■			6	5 mins	2 mins		
NF EN 60156	■	■	■				■	■	■			6	5 mins	2 mins		
SABS EN 60156	■	■	■				■	■	■			6	5 mins	2 mins		
VDE 0370 part 5	■	■	■				■	■	■			6	5 mins	2 mins		
AS1767.2.1	■	■	■				■	■	■			6	5 mins	2 mins		
PA SEV EN 60156	■	■	■				■	■	■			6	5 mins	2 mins		
JIS C 2101-99 (M)	■		■				■		■			5 x 2	2 mins	1 min		
JIS C 2101-99 (S)	■	■	■				■					1 x 5	2 mins (x5)	N/A		
ASTM D 1816-04	■	■	■	■			■		■			5	3 mins	1 min 15s		
ASTM D 877A-02	■	■				■		■				5	2 mins	1 min		
ASTM D 877B-02	■	■				■		■				1 x 5	2 mins (x5)	N/A		
Custom tests (x3) (Programmable)	■	■	1.0 to 7.0				■	■	■			5, 6 or 10	10s to 600s	10s to 600s		
Withstand A	■	■	2.5 to 4.0				■	■	■			1	10s to 600s	N/A		
Withstand B	■	■	2.5 to 4.0				■	■	■			2	10s to 600s	N/A		
BS 5730a AD 30kV/40kV	■	■	30 kV = 2.5	40kV = 4.0			■	■	■			3	10s to 600s	N/A		
BS 5730a BCEF 22kV/30kV	■	■	22 kV = 2.5	30kV = 4.0			■	■	■			3	10s to 600s	N/A		






















ORDERING INFORMATION

Description	Order Code	Description	Order Code
OTS60PB	Configured* Page 8		
OTS80PB	Configured* Page 8		
OTS60AF	Configured* Page 7		
OTS80AF	Configured* Page 7		
OTS100AF	Configured* Page 7		
Included accessories (On all configurations)			
Vessel 400 ml assembly			
12 V vehicle charger lead (OTS PB battery configurations only)			
Magnetic bead stirrers (2 off)			
Magnetic bead retriever			
User manual CD			
PowerDB Lite software			
Electrode gauge set 1, 2, 2.5, 2.54 mm	1002-144		
Configured accessories (to order additional or spare)			
OTS IEC60156 Electrode set contents - supplied in accessory case			
12.7 mm spherical electrodes (2)			
36 mm mushroom electrodes (2)			
Magnetic stirrer bar (2)			
Magnetic stirrer bar retriever (1)			
Gap gauge set	1001-477		
OTS ASTM D877/D1816 Electrode set contents – supplied in accessory case			
25.4 mm standard (sharp edges) cylindrical electrodes (2)			
25.4 mm non-standard (round edges) cylindrical electrodes (2)			
36 mm mushroom electrodes (2)			
Magnetic stirrer bar (2)			
Magnetic stirrer bar retriever (1)			
Gap gauge set	1001-478		
Full electrode set (covers IEC and ASTM standards)			
12.7 mm spherical electrodes (2)			
36 mm mushroom electrodes (2)			
25.4 mm standard (sharp edges) cylindrical electrodes (2)			
25.4 mm non-standard (round edges) cylindrical electrodes (2)			
Magnetic stirrer bar (2)			
Magnetic stirrer bar retriever (1)			
Gap gauge set	1001-479		
Vessel lid mounted impeller (ASTM or IEC) for use with 400 ml vessel	1001-102		
Carry bag (padded) OTS80PB	1001-476		
Carry bag (padded) OTS60PB	1001-480		
Optional accessories			
Vessel 400 ml assembly (no electrodes supplied)		1001-473	
Vessel 150 ml assembly (no electrodes supplied)		1001-474	
VCM100D digital voltage checker		1001-105	
VCM80D digital voltage checker		1001-801	
Printer paper, 20 rolls (4 rolls supplied if printer configured)		1008-030	
Barcode reader, USB		1001-047	
Transport case (with wheels)		1001-475	
ASTM alternative propeller shaft assy		1007-153	
IEC alternative propeller shaft assy		1007-154	
Electrodes - Spherical (pair)		6220-484	
Electrodes - Mushroom (pair)		6220-580	
Electrodes - Cylindrical (pair)		6220-483	
Electrodes - Non-standard cylindrical with 0,5 mm edge radius (pair)		6220-538	
Electrode gauge set 1, 2, 2.5, 2.54 mm		1002-144	
OTS Super-user kit:			
400 ml vessel kit			
150 ml vessel kit			
Additional IEC impeller			
Additional ASTM impeller			
Standard impeller			
Vessel lid mounted impeller (ASTM D1816) for use with 400 ml vessel			
'Megger Guide to break down testing' booklet			
Oil testing application note			
Carry case		1007-467	
* See ordering configuration on previous page			

ORDERING CONFIGURATION

Example of an ordering configuration:-

OTS80PB-UK-1-A-P-5-C = This order is for an OTS80PB with UK power lead, Sealed LEAD ACID battery, ASTM electrode set, internal printer, super user kit and carry case.

Model:	OTS	PB-	-	-	-	-	-	-	-	Weight
Select a model	60 kV	60PB	↑	↑	↑	↑	↑	↑	↑	29.5 kg
	80 kV	80PB								29.5 kg
Select Power Cord		EU Lead	EU	↑	↑	↑	↑	↑	↑	
		UK Lead	UK							
		US Lead	US							
		AU Lead	AU							
		NO Plug	BL							
Battery options		Sealed LEAD ACID (OTS80PB ONLY)	1	↑	↑	↑	↑	↑	↑	3.3 kg
		NiMH (OTS60PB and OTS80PB ONLY)	2							0.8 kg
		No Battery	X							
Electrode options		ASTM set	A	↑	↑	↑	↑	↑	↑	
		IEC set	E							
		Full set	U							
Printer		Internal printer	P	↑	↑	↑	↑	↑	↑	0.54 kg
		No printer	X							0.08 kg
Stirrer options		400 ml			Stirrer lid fitted	4	↑	↑	↑	0.3 kg
		400 ml			Stirrer lid not fitted	X				0.3 kg
Carry case		Carry case (PB Models only)	C	↑	↑	↑	↑	↑	↑	1.3 kg
		No carry case	X							

















OTS PB and OTS AF Range

Fully automatic insulating oil dielectric breakdown testing

ORDERING CONFIGURATION

Example of an ordering configuration:-

OTS100AF-USA-P4 = This order is for an OTS100AF with US power lead, ASTM electrode set, internal printer and lid stirrer.

Model:	OTS	AF-	-	-	-	-	Weight
Select a model	60 kV	60AF					29.5 kg
	80 kV	80AF					29.5 kg
	100 kV	100AF					
Select Power Cord		EU Lead	EU				
		UK Lead	UK				
		US Lead	US				
		AU Lead	AU				
		NO Plug	BL				
Electrode options			ASTM set	A			
			IEC set	E			
			Full set	U			
Printer			Internal printer	P			0.54 kg
			No printer	X			0.08 kg
Stirrer options					Stirrer lid fitted	4	0.3 kg
					Stirrer lid not fitted	X	0.3 kg